



Power LG backpack sprayer (15 litre)		11636601	111209
<b>Accessories (Pictures see page 30)</b>			
Vario Gun, stepless variable one-hand operation from mist to jet		11558501	100821
Glass-fibre reinforced plastic extension tube, length 1 m		11497403	100890
Telescopic extension 45-90 cm, plastic/aluminium		11659001-SB	030098
Spray hood, oval, yellow, to insert		<b>NEW</b> 11871101	110066
Spray hood yellow, 12.5 cm, to insert		<b>NEW</b> 11864801	110042
Spray boom, plastic, max. 4 bar, to insert, with 4 fanjet nozzles		11659801-SB	100975
Spray boom, alu, max. 7 bar, to insert, with 4 fanjet nozzles		<b>NEW</b> 11870901	110059
<b>No Gasket set consisting of:</b>		11478804-SB	700977
1	Sleeve		
2	O-Ring 52x5		
3	Ball		
4	Membrane		
5	O-Ring 61x5		
10	O-Ring 7.66x1.78		
<b>No Spare parts</b>			
6	Carrying belt, pair (a pair)	11563403-SB	111230
7	Trigger and hose assy.	11637602-SB	710525
8	Spray tube 50 cm, straight, brass	11310402	710297
9	Adjustable nozzle 1.3 mm plastic-brass	11859401-SB	040493
11	Pump lever	11465202	
12	Lid assy. with gasket	10397202-SB	151007
13	Filter screen assy.	77009699-SB	151038