


AS 1200 AC1




i Nr. 1 bis 13: Diese Ersatzteile finden Sie auf www.birchmeier.com
 No. 1 to 13: You will find these spare parts on www.birchmeier.com
 N° 1 à 13: Vous trouverez ces pièces de rechange sur www.birchmeier.com
 N. da 1 a 13: Questi ricambi sono disponibili su www.birchmeier.com

11	Wartungsset AS 1200 Maintenance kit AS 1200 Kit d'entretien AS 1200 Kit di manutenzione AS 1200	Art.Nr. 12050801
14	Gehäuse Body Boîtier Alloggiamento	Art.Nr. 12055701
15	Schutzgitter Protection grid Grille de protection Protezione	Art.Nr. 12055801
16	Impeller Electric ducted fan (EDF) Hélice Girante	Art.Nr. 12128001
17	Kabelbaugruppe (Folie + Zusatz) Cable assembly (foil + additional) Ensemble de câblage (film + ajout) Assemblaggio cavi (lamina + aggiuntivo)	Art.Nr. 12049002
18	Zuleitung Supply line Alimentation Linea di alimentazione	Art.Nr. 12127901
19	Wasseranschluss Messing vernickelt Water connection brass nickled Alimentation en eau laiton nicklé Raccordo dell'acqua ottone nichelato	Art.Nr. 12039102


20	Magnetventil Magnet valve Électrovanne Elettrovalvola	Art.Nr. 12055501
21	Elektronik Electronics Électronique Elettronica	Art.Nr. 12128101
22	Drücker Trigger Gâchette Grilletto	Art.Nr. 12055601
23	Folientastatur AS 1200 Membrane keyboard AS 1200 Clavier à membrane AS 1200 Tastiera a membrana AS 1200	Art.Nr. 12038802
24	Flüssigkeitsleitung Liquid line La conduite de liquide Condotta del liquido	Art.Nr. 12055301
25	Kunststoffimpellerhalterung Plastic EDF holder Support de l'hélice roue en plastique Staffa di plastica della girante	Art.Nr. 12055101

AS 1200 AC1


LED Akku-Sprühgebläse
 LED Battery spray blower
 LED pulvérisateur souffleur à batterie
 LED irroratrice con soffiatore a batteria




Kein Turbo + Ladezustand (100%)
 No turbo + Charge state (100%)
 Pas de turbo + Etat de charge (100%)
 Nessun turbo + Stato di carica (100%)




Kein Turbo + Ladezustand (10%)
 No turbo + Charge state (10%)
 Pas de turbo + Etat de charge (10%)
 Nessun turbo + Stato di carica (10%)




Standby
 Standby
 Mode veille
 Standby




Akku leer
 Battery empty
 Batterie vide
 Batteria scarica




Überhitzung
 Overheating
 Surchauffe
 Surriscaldamento




Elektronikfehler
 Electronic fault
 Défaut électronique
 Guasto elettrico




Motorfehler
 Motor fault
 Défaut moteur
 Guasto al motore




Ventilstörung
 Valve fault
 Défaut soupape
 Interferenza con la valvola




Überspannung
 Overvoltage
 Surtension
 Sovratensione



Gesperrt durch Zusatzanwendung
 Blocked by additional application
 Verrouillé par une application supplémentaire
 Bloccato da un'applicazione aggiuntiva



Fehler Zusatzanwendung
 Error additional application
 Erreur application supplémentaire
 Errore nell'applicazione aggiuntiva



Überstrom Zubehörschnittstelle
 Overcurrent at accessory interface
 Surintensité interface accessoire
 Sovracorrente interfaccia accessori